
ConceptBlindsDirect

How to fit and operate your Concept Sherwood Wooden blind



Getting started


YOU WILL NEED:

- A drill with correct bit
- A crossheaded screwdriver
- A metal tape measure
- A pencil
- Your brackets are packed separately in the box. Please ensure you've located them before disposing of the packaging.
- The brackets are a universal type that can be used to top fix the blind into a recess or face fix into a frame or a wall.
- A centre support bracket is also supplied with larger blinds that can be top fixed or face fixed. This should be located as close to the centre of the blinds as possible, avoiding any slat support ladders.
- Please read the following instructions carefully before you start fitting your blind.

To fix the brackets

1

- Locate the measuring points you used to calculate the width of the blind. You may be able to use the blind as a template.
- 2. Ensure the brackets are positioned a suitable distance away from any window handles or obstructions to allow the blind to operate smoothly.
- 3. Make sure you allow the correct amount of space for the blind to fit snugly between the brackets.
- 4. Hold a bracket in position and mark where the screws will go, using the relevant holes in the bracket as a guide.
- 5. If you're fitting to a wall or lintel, use a drill with the suitable sized bit to make your holes, and push in wallplugs.
- 6. If you're fitting into a wooden frame, screw your brackets into position. You may want to make pilot holes to allow easier fixing of the screws.
- 7. Fix the bracket into place and repeat on the other side of the blind.



1. Open the doors on the brackets and slide the blind into place with the controls facing towards you.



 To lock the headrail into position, push down and snap shut the hinge doors.

	4		
_	_		
		107	50

To fix the valance


3


1. Fit the valance clips into the groove on the back of the valance at equal distance apart along it's length.





- 2. Line up the valance clips with the hooks on the blind. You can easily slide the hooks on the head rail to match the position of the hooks.
- 3. Push the valance into place.
- To fit the valance returns to the sides of the valance (if required) slide the corner clips into position in the grove on the back of the valance.
- 5. Push the valance returns onto the clip.





Safety tips:

There are things that you can do to reduce risk in your home.

- Move beds, cots and furniture away from the window.
- Do not let cords or chains hang loose.
 Make sure they are kept out of reach of children at all times.
- Do not tie loose cords and chains together.
- Check the condition
 of all safety devices

if not used regularly and replace if the device is faulty.

Operating your blind:

Operating your blind is easy. Just follow these instructions.

- There are two controls that will operate the blind - a tilt control and a raise lower control.
- To raise the blind, pull the cord down until the blind is at the height you want and lock into place by moving the cords across the blind.
- To lower the blind, release the cord by moving them away from the blind, then let the cord slide through your fingers.
- Slats should be open when raising or lowering the blind.
- To adjust the angle of the slats, operate the tilt control cords as required.

How to fit and use your Child Safety Devices


Warning

5

Blinds can be potentially dangerous to small children. Please be aware that swallowing small parts can cause internal asphyxiation. Looped or low hanging cords, chains or tapes can create hazardous loops which could lead to the risk of strangulation. We do everything we can to ensure your chosen product is child safe. As a minimum all of our blinds meet the European Standard BS EN 13120 for safety. Our instructions and the supplied Child Safety device(s) are intended for you to ensure that your blind is as safe as possible.

The information below gives guidance for fitting the provided child safety devices. All safety devices must be correctly installed for the protection from strangulation of young children and the proper use of the blind. Please read the instructions carefully and keep safe for future reference.

Only use the devices and cords provided with your blind. Videos showing how to fit and reconnect child safety devices are available, along with replacements at **www.makeitchildsafe.co.uk**.



Blinds that require a safety cleat must not be installed less than 1.5m from the floor. Safety cleats are designed to keep cords taut and out of reach of children – always wrap the cord around the cleat.

Fix the safety cleat to the wall with 2 screws in a position that's out of reach of children. Install it as close to the head rail as possible, ensuring that it is no closer to the floor than 1.5m. See fig. 1.



fig 1

If more than one cleat is required for the complete amount of cord to be wrapped around, ensure that they are positioned no further apart than 20cm and both no closer to the floor than 1.5m.



To re-assemble the cord consolidator

Note - the consolidator is designed to come apart to remove a hazardous loop.

To reconnect the consolidator, check that it is not damaged, then re-insert the free cords as described below. If any slack cording appears above the consolidator, lower the blind so that it is straight and raise it again.

1. Gather the loose cords together and align the knots. See fig.1.





2. Insert the knotted ends into the groove at the top of the consolidator, ensure that the knots are secured below the central panel. See fig. 2





3. Secure the two halves together. See fig. 3.



