ConceptBlindsDirect


How to Fit and Operate your Styleline Express Wood Blind

(Read Child Safety information first) Select mounting position to suit: Inside Mounting: Outside Mounting Top / Ceiling Mounting: 1) Measure where the blind is to hang. 2) Ensure it is centred & level. 3) Pencil mark each side of blind as fixing points of brackets. 4) Hold bracket in position, door open - mark fix points.

- Repeat for both. 5) Insert & tighten screws through slots.
- 6) Check correctly positioned.

HOW TO INSTALL BLIND


- 7) Slide headrail into brackets cords out.
- 8) Close bracket doors securely locked.



Attach a minimum of 2 plastic clips over the edge of the headrail & engage. DO NOT FIT VALANCE until blind is safely in place. Fit valance into clips. Back of clip slots onto



TIP – Always Fit Valance Clips before fitting the Blind into the brackets. It is difficult to fit the clips after the Blind has been installed



D.I.Y OR PROFESSIONAL INSTALLATION CHILD SAFE CORD CLEAT <u>MUST</u> BE FITTED!

Correctly installed at 1.5m (60") from the floor, this supplied nonintegral Child Safety Device is screw fixed & stores excess cord out of a child's reach.



OPERATING (Please read carefully the Child Safety advice on labels attached to your Blind)

- 1) Stop rings on cords prevent pull-through and MUST NOT be disconnected or removed.
- 2) Break-apart Child Safety Joining device on cords MUST NOT be removed.
- 3) BSEN13120 requires Cord Cleat(s) at 1.5m height. These MUST be installed.
- 4) LEFT SIDE CORDS of an SLX blind rotate the slats
- 5) RIGHT SIDE CORD(S) of an SLX Blind raise / lower. (May be combined in 1 for safety reasons)
- 6) Pull to raise & lock mechanism in headrail will keep blind up when carefully released.
- 7) Support the weight of the blind whilst raising.
- 8) Lower Blind by holding RIGHT cord(s) & gently release from lock mechanism. ALWAYS support the weight of the blind as it lowers. DO NOT let blind fall under its own weight.

ConceptBlindsDirect

MAINTENANCE


SLX real wood venetian blinds are designed to last a long time if proper care is taken of them and do not need much effort to maintain.

Regular cleaning will help the visual quality remain the same but in high sun positions some fading is possible. Operating cords and internal operating mechanisms are best maintained professionally. Contact installer for such maintenance / repair.

Use an ostrich feather duster regularly to remove light dust & any other loose bits that may be on the slats. To give a final thorough clean, use a slightly dampened cloth to wipe slats.

DO NOT use soap & water to clean SLX real wood venetian blinds in case water seeps into the slats, which will cause warpage. The location of the window can affect whether an SLX real wood venetian is appropriate or not. This is a natural product & high intensity direct sunlight may magnify the heat impact on the slats, rapidly drying them out & encouraging warping. Humidity is never good for real wood, so bear this is mind if choosing to site them in kitchens or conservatories subject to wide temperature variations.

PLEASE KEEP BABY'S COT OR CHILD'S BED AWAY FROM WINDOWS AND ENSURE THAT ALL **BLIND & CURTAIN CORDS ARE KEPT OUT OF REACH.**



cords or chains out of reach of children.

CHILD SAFETY

Child Safety Devices are fitted to this blind or are supplied as non-integral components. This is required to comply with BS EN 13120.

Please ensure your blind installer explains the requirements to your satisfaction and is able to install all non-integral safety items or if you are fitting this blind yourself, that you understand and are able to do so.

Information about blinds and Child Safety can be found at www.bbsa.org.uk & at www.makeitsafe.org.uk





This label accompanies a non-integral safety device (cleat) designed to wrap all excess cord around away from a child's reach at a height of 1.5m (approx. 60") from floor level.